

WORKSHOP 1: Analysis of genome-wide transcription factor-binding sites using ChIP-seq data

TASK1: Create an environment using mamba, and name the environment “workshop1”

Address: 10.139.1.132 Username: binf6_03 Password: binf-GiantDingo76

mamba create -n workshop1 python=3.7

mamba activate workshop1

mamba install -c bioconda fastqc seqtk bowtie2 samtools macs2 idr

TASK2: PIPELINE

binf6_03@binf6000-03-32: ~

```
GNU nano 6.2 pipe.
#!/bin/bash

# Define a new output directory for the full analysis
FULL_OUTPUT_DIR="full_output"

# Step 1: Quality Control
echo "Running FastQC for quality control on the full dataset..."
mkdir -p ${FULL_OUTPUT_DIR}/metrics # Create a metrics directory inside the full_output directory
fastqc data/*.fastq.gz -o ${FULL_OUTPUT_DIR}/metrics/ # Run FastQC on all fastq.gz files in the data directory and output the results to the metrics directory
```

```
# Step 2: Alignment with Bowtie2
echo "Aligning reads with Bowtie2 for the full dataset..."
mkdir -p ${FULL_OUTPUT_DIR}/alignment # Creates a directory to store alignment outputs.
# Align the control sample to the reference genome
bowtie2 -x reference/bowtie2_index/genome \ # Specifies the path to the pre-built Bowtie2 index for the reference genome.
-U data/control.fastq.gz \ # Specifies the path to the FASTQ file for the control sample.
> ${FULL_OUTPUT_DIR}/alignment/control.sam # Directs the SAM formatted alignment output to a file named control.sam in the alignment directory.
# Align treatment replicate 1 to the reference genome
bowtie2 -x reference/bowtie2_index/genome \ # Specifies the path to the Bowtie2 index.
-U data/treatment_rep1.fastq.gz \ # Specifies the path to the FASTQ file for treatment replicate 1.
> ${FULL_OUTPUT_DIR}/alignment/treatment_rep1.sam # Directs the SAM formatted alignment output for treatment replicate 1 to its file.
# Align treatment replicate 2 to the reference genome
bowtie2 -x reference/bowtie2_index/genome \ # Specifies the path to the Bowtie2 index for the reference genome.
-U data/treatment_rep2.fastq.gz \ # Specifies the path to the FASTQ file for treatment replicate 2.
> ${FULL_OUTPUT_DIR}/alignment/treatment_rep2.sam # Directs the SAM formatted alignment output for treatment replicate 2 to its file.
```

```
# Step 3: SAM to BAM Conversion and Mapping Quality Check
echo "Converting SAM to BAM and checking mapping quality for the full dataset..."
# Convert SAM file to BAM for the control sample
samtools view -bS ${FULL_OUTPUT_DIR}/alignment/control.sam \
> ${FULL_OUTPUT_DIR}/alignment/control.bam # Uses samtools to convert the SAM format file of the control sample to BAM format for efficient storage and analysis.
# Convert SAM file to BAM for treatment replicate 1
samtools view -bS ${FULL_OUTPUT_DIR}/alignment/treatment_rep1.sam \
> ${FULL_OUTPUT_DIR}/alignment/treatment_rep1.bam # Converts the SAM format file of treatment replicate 1 to BAM format.
# Convert SAM file to BAM for treatment replicate 2
samtools view -bS ${FULL_OUTPUT_DIR}/alignment/treatment_rep2.sam \
> ${FULL_OUTPUT_DIR}/alignment/treatment_rep2.bam # Converts the SAM format file of treatment replicate 2 to BAM format.
# Generate mapping quality report for the control sample
samtools flagstat ${FULL_OUTPUT_DIR}/alignment/control.bam \
> ${FULL_OUTPUT_DIR}/metrics/control_mapping_quality.txt # Generates a statistical report on the mapping quality of the control sample, saving it to a text file.
# Generate mapping quality report for treatment replicate 1
samtools flagstat ${FULL_OUTPUT_DIR}/alignment/treatment_rep1.bam \
> ${FULL_OUTPUT_DIR}/metrics/treatment_rep1_mapping_quality.txt # Generates a statistical report on the mapping quality of treatment replicate 1, saving it to a text file.
# Generate mapping quality report for treatment replicate 2
samtools flagstat ${FULL_OUTPUT_DIR}/alignment/treatment_rep2.bam \
> ${FULL_OUTPUT_DIR}/metrics/treatment_rep2_mapping_quality.txt # Generates a statistical report on the mapping quality of treatment replicate 2, saving it to a text file.
```

```
(workshop1) binf6_03@binf6000-03-32:~$ cd full_output/metrics
(workshop1) binf6_03@binf6000-03-32:~/full_output/metrics$ ls
control_fastqc.html control_fastqc.zip control_mapping_quality.txt treatment_rep1_fastqc.html treatment_rep1_fastqc.zip treatment_rep1_mapping_quality.txt treatment_rep2_fastqc.html treatment_rep2_fastqc.zip treatment_rep2_mapping_quality.txt
(workshop1) binf6_03@binf6000-03-32:~/full_output/metrics$ cd
(workshop1) binf6_03@binf6000-03-32:~$ cd full_output/alignment
(workshop1) binf6_03@binf6000-03-32:~/full_output/alignment$ ls
control.bam control.sam treatment_rep1.bam treatment_rep1.sam treatment_rep2.bam treatment_rep2.sam
```

```
# Step 4: Peak Calling with MACS2
echo "Calling peaks with MACS2 using fixed extension size for the full dataset..."
mkdir -p ${FULL_OUTPUT_DIR}/peaks # Create a directory for storing the peak calling results.
# Calling peaks for treatment replicate 1 against control
macs2 callpeak -t ${FULL_OUTPUT_DIR}/alignment/treatment_rep1.bam \ # Specify the treatment replicate 1 BAM file as the target.
-c ${FULL_OUTPUT_DIR}/alignment/control.bam \ # Specify the control BAM file for comparison.
-f BAM -g dm -n treatment_rep1 \ # Define the format as BAM, specify the genome size (dm for Drosophila melanogaster), and output name.
--outdir ${FULL_OUTPUT_DIR}/peaks -q 0.05 \ # Set the output directory for peak files and set the q-value (FDR-adjusted p-value) cutoff for peak detection.
# The q-value represents the minimum FDR at which the test may be called significant. A q-value of 0.05 means that you're willing to accept a 5% of the identified peaks could be false positives.
--call-summits --nomodel --extsize 147 # Call peak summits, bypass the model building step, and set a fixed extension size of 147 bp to simplify analysis.
# Calling peaks for treatment replicate 2 against control
macs2 callpeak -t ${FULL_OUTPUT_DIR}/alignment/treatment_rep2.bam \ # Specify the treatment replicate 2 BAM file as the target.
-c ${FULL_OUTPUT_DIR}/alignment/control.bam \ # Specify the control BAM file for comparison.
-f BAM -g dm -n treatment_rep2 \ # Define the format as BAM, specify the genome size (dm for Drosophila melanogaster), and name the output.
--outdir ${FULL_OUTPUT_DIR}/peaks -q 0.05 \ # Set the output directory for peak files and the q-value cutoff for peak detection.
--call-summits --nomodel --extsize 147 # Call peak summits, bypass the model building step, and set a fixed extension size of 147 bp.
```

```
chr2L 887987 887988 treatment_rep1_peak_83 8.40418
chr2L 1006775 1006776 treatment_rep1_peak_84 117.643
chr2L 1063014 1063015 treatment_rep1_peak_85 3.49789
chr2L 1072389 1072390 treatment_rep1_peak_86 31.1469
chr2L 1074724 1074725 treatment_rep1_peak_87 6.24684
treatment_rep1_summits.bed
```

```
chr2L 885175 885176 treatment_rep2_peak_83 13.8
chr2L 887972 887973 treatment_rep2_peak_84 9.70
chr2L 901587 901588 treatment_rep2_peak_85 3.06
chr2L 1006773 1006774 treatment_rep2_peak_86 82.5
chr2L 1072408 1072409 treatment_rep2_peak_87 31.2
treatment_rep2_summits.bed
```

```
# Step 5: Reproducibility Assessment with IDR
echo "Assessing reproducibility with IDR for the full dataset..."
mkdir -p $(FULL_OUTPUT_DIR)/idr # Create a directory for storing idr results.
# Run IDR (Irreproducible Discovery Rate) analysis to compare peak calls between the two treatment replicates
idr --samples $(FULL_OUTPUT_DIR)/peaks/treatment_rep1_peaks.narrowPeak \ # Specify first set of peaks for comparison
$(FULL_OUTPUT_DIR)/peaks/treatment_rep2_peaks.narrowPeak \ # Specify second set of peaks for comparison
--output-file $(FULL_OUTPUT_DIR)/idr/treatment_idr_output.txt \ # Designate file to write IDR analysis results
--plot \ # Generate plots summarizing the IDR analysis
--log-output-file $(FULL_OUTPUT_DIR)/idr/treatment_idr.log # Log file for detailed IDR analysis output
# Convert p-value to -log10(p-value) in column 12
awk 'BEGIN {OFS="\t"} { $12 = -log($12)/log(10); print }' $(FULL_OUTPUT_DIR)/idr/treatment_idr_output.txt > $(FULL_OUTPUT_DIR)/idr/treatment_idr_output_log10p.txt
# Step 6: Filtering Peaks Based on IDR Output
echo "Filtering significant, reproducible peaks based on IDR output for the full dataset..."
mkdir -p $(FULL_OUTPUT_DIR)/final_peaks # Create a directory to hold the final set of peaks deemed significant and reproducible.
# Filter peaks based on p-value (in column 12)
awk '$12 < 0.05' $(FULL_OUTPUT_DIR)/idr/treatment_idr_output_log10p.txt \
> $(FULL_OUTPUT_DIR)/final_peaks/significant_reproducible_peaks.bed #Final output destination.
```

chr2R	15816846	15822542	1000	65.86106	-1	-1	4667	5.000000	-0.68897	15816889	15822542	31.39334	2955	15816846	15822389	34.46772	1693
chr2R	11407198	11411117	1000	61.30062	-1	-1	3725	5.000000	-0.68897	11407198	11411117	31.16116	1470	11407198	11407274	30.13946	1113
chr3L	3765741	3769831	1000	59.13372	-1	-1	3584	5.000000	-0.68897	3765741	3769831	28.60205	1540	3765741	3769831	28.60205	1540
chr2R	8250108	8253286	1000	57.23418	-1	-1	1664	5.000000	-0.68897	8250108	8253286	28.61011	853	8250108	8253286	28.61011	853
chr2R	14431010	14436080	1000	52.50832	-1	-1	2593	5.000000	-0.68897	14431010	14436080	28.74322	1005	14431010	14435953	23.76510	1875
chr2R	20905081	20905013	1000	50.66346	-1	-1	1351	5.000000	-0.68897	20905081	20905013	25.11064	849	20905081	20905013	25.11064	849
chr2L	3784187	3787617	1000	47.59915	-1	-1	2089	5.000000	-0.68897	3784187	3787617	23.53507	1105	3784187	3787617	23.53507	1105
chr2R	23000438	23003176	1000	46.46851	-1	-1	1685	5.000000	-0.68897	23000438	23003176	22.16911	827	23000438	23003176	22.16911	827
chr2R	29311716	29314460	1000	44.72700	-1	-1	1185	5.000000	-0.68897	29311716	29314460	19.27883	1508	29311716	29314439	25.44817	953
chr2R	17140805	17143782	1000	40.23602	-1	-1	756	5.000000	-0.68897	17140805	17143782	21.52815	1307	17140805	17143785	18.76684	1587
chr3L	709868	713470	1000	39.97807	-1	-1	2688	5.000000	-0.68897	709868	713470	22.76562	1548	709868	713470	22.76562	1548
chr3L	10320245	10322223	1000	36.77544	-1	-1	766	5.000000	-0.68897	10320245	10322223	21.06345	867	10320245	10322213	18.71199	683
chr3R	5297200	5301501	1000	39.40023	-1	-1	1597	5.000000	-0.68897	5297200	5301501	22.52149	1499	5297200	5301501	22.52149	1499
chr3L	1490577	1493603	1000	39.33078	-1	-1	1471	5.000000	-0.68897	1490577	1493603	21.15310	1401	1490577	1493520	21.15310	1401
chr2L	15652378	15654731	1000	38.72299	-1	-1	1152	5.000000	-0.68897	15652378	15654731	20.68340	1137	15652378	15654731	20.68340	1137
chr2R	8747979	8749889	1000	37.93001	-1	-1	1341	5.000000	-0.68897	8747979	8749889	18.16787	957	8747979	8749889	18.16787	957
chr4	403476	407635	1000	37.29410	-1	-1	2294	5.000000	-0.68897	403476	407635	16.36025	1459	403476	407635	16.36025	1459
chr4	4917629	4920230	1000	36.74131	-1	-1	952	5.000000	-0.68897	4917629	4920230	18.98715	780	4917629	4920230	18.98715	780
chr2L	15594051	15598977	1000	36.26106	-1	-1	885	5.000000	-0.68897	15594051	15598977	18.75228	904	15594051	15598977	18.75228	904
chr3R	29713081	29718338	1000	36.10140	-1	-1	1102	5.000000	-0.68897	29713081	29718338	18.21113	1312	29713081	29718346	17.99027	890
chr2L	10984538	10987572	1000	35.97155	-1	-1	1616	4.933538	-0.68897	10984538	10987572	14.94601	1419	10984538	10987551	21.02554	790
chr3R	12489646	12489734	1000	35.54567	-1	-1	883	5.000000	-0.68897	12489646	12489734	16.45577	835	12489646	12489715	19.08590	1618
chr3L	23157477	23160009	1000	35.27787	-1	-1	1944	5.000000	-0.68897	23157477	23160009	19.37203	1022	23157477	23160009	19.37203	1022
chr3R	12478945	12481724	1000	34.91052	-1	-1	942	5.000000	-0.68897	12478945	12481724	17.58954	998	12478945	12481722	17.32098	813
chr3R	16858261	16858261	1000	34.87539	-1	-1	1393	5.000000	-0.68897	16858261	16858261	20.08492	857	16858261	16858195	14.79047	653
chr3L	15379418	15379418	1000	34.53685	-1	-1	1007	5.000000	-0.68897	15379418	15379418	17.18245	1021	15379418	15379416	17.35440	1493
chr2L	17750373	17753315	1000	34.48618	-1	-1	1473	5.000000	-0.68897	17750373	17753315	16.17680	657	17750373	17753290	18.30398	1154
chr2L	19324811	19327657	1000	34.21655	-1	-1	1110	5.000000	-0.68897	19324811	19327657	17.89076	1523	19324811	19327595	16.32579	1452
chr2L	18620586	18622792	1000	33.90418	-1	-1	1420	5.000000	-0.68897	18620586	18622792	18.14444	634	18620586	18622700	15.75594	600
chr2L	20523901	20524487	1000	33.78508	-1	-1	1404	5.000000	-0.68897	20523901	20524487	19.24829	1470	20523901	20524487	19.24829	1470
chr3L	21602943	21606032	1000	33.14731	-1	-1	1536	4.681766	-0.68897	21602943	21606032	14.20872	1122	21602943	21606032	18.95859	1098
chr2L	489632	493325	1000	32.94414	-1	-1	3818	5.000000	-0.68897	489632	493325	17.78562	2094	489632	493325	17.78562	2094
chr2L	18237108	18237108	1000	32.83453	-1	-1	1334	5.000000	-0.68897	18237108	18237108	16.25132	1813	18237108	18236665	14.01617	1445
chr2R	20939720	20939526	1000	32.17441	-1	-1	1342	5.000000	-0.68897	20939720	20939526	16.89755	1157	20939720	20939339	15.27686	767
chr3L	9053717	9056305	1000	32.06366	-1	-1	1157	5.000000	-0.68897	9053717	9056305	17.41778	1063	9053717	9056261	17.41778	1063
chr2L	3471130	3474261	1000	31.91503	-1	-1	1207	3.962526	-0.68897	3471130	3474261	19.80491	1088	3471130	3474261	19.80491	1088
chr4	4941385	4941358	1000	31.97454	-1	-1	1722	5.000000	-0.68897	4941385	4941358	14.59135	1273	4941385	4941358	14.59135	1273
chr2L	1769546	17698546	1000	31.71828	-1	-1	2572	5.000000	-0.68897	1769546	17698546	16.09239	1730	1769546	17698524	15.62589	1746
chr2L	5364656	5367558	1000	31.64815	-1	-1	1280	5.000000	-0.68897	5364656	5367558	14.12543	1478	5364656	5367558	14.12543	1478
chr2L	21406663	21409152	1000	31.58555	-1	-1	1582	5.000000	-0.68897	21406663	21409152	17.16122	1528	21406663	21409152	17.16122	1528
chr2L	18515127	18518393	1000	31.12202	-1	-1	1357	5.000000	-0.68897	18515127	18518393	15.24316	1721	18515127	18518321	14.42243	558
chr2L	5289157	5290762	1000	31.04047	-1	-1	749	4.481441	-0.68897	5289157	5290762	17.52078	774	5289157	5290762	17.52078	774
chr2L	12426025	12425806	1000	30.92734	-1	-1	969	5.000000	-0.68897	12426025	12425806	15.71581	1012	12426025	12425794	14.76447	1030
chr2L	9464072	9465785	1000	30.57547	-1	-1	567	4.716044	-0.68897	9464072	9465785	13.20727	607	9464072	9465785	13.20727	607
chr3L	50434	508620	1000	30.54381	-1	-1	376	5.000000	-0.68897	50434	508620	14.02635	1785	50434	508620	14.02635	1785
chr2L	7255746	7255834	1000	30.45082	-1	-1	2500	5.000000	-0.68897	7255746	7255834	14.47154	1338	7255746	7255834	14.47154	1338
chr2L	1026002	1026451	1000	30.52374	-1	-1	650	4.722004	-0.68897	1026002	1026451	11.57045	483	1026002	1026451	11.57045	483
chr4	424368	424641	1000	30.49531	-1	-1	1721	3.012253	-0.68897	424368	424641	15.36488	1568	424368	424641	15.36488	1568
chr2L	1863468	1863668	1000	29.87691	-1	-1	1151	4.384729	-0.68897	1863468	1863668	17.30095	1391	1863468	1863668	17.30095	1391
chr2R	19520357	19522559	1000	29.81669	-1	-1	1444	5.000000	-0.68897	19520357	19522559	15.37634	833	19520357	19520357	15.37634	833
chr2R	6149896	6153091	1000	29.64053	-1	-1	1288	5.000000	-0.68897	6149896	6153091	15.23493	1615	6149896	6153032	14.35560	1729
chr2R	14389466	14389466	1000	29.63808	-1	-1	2964	3.920053	-0.68897	14389466	14389466	17.89883	1964	14389466	14389466	17.89883	1964
chr3L	7163180	7163750	1000	29.54195	-1	-1	1332	4.612664	-0.68897	7163180	7163750	16.26833	1087	7163180	7163750	16.26833	1087
chr3R	21521827	21521494	1000	29.53888	-1	-1	1676	4.738338	-0.68897	21521827	21521494	13.51230	1140	21521827	21521494	13.51230	1140
chr3L	11046083	11046083	1000	29.50841	-1	-1	1987	4.030171	-0.68897	11046083	11046083	17.71708	1747	11046083	11046083	17.71708	1747
chr3L	10807007	10807007	1000	29.49065	-1	-1	1484	4.900700	-0.68897	10807007	10807007	14.02080	793	10807007	10807007	14.02080	793
chr2R	21237736	21239531	1000	29.34975	-1	-1	1288	4.940708	-0.68897	21237736	21239531	15.75550	930	21237736	21237736	15.75550	930
chr2L	18237970	18240191	1000	29.13756	-1	-1	690	4.998467	-0.68897	18237970	18240191	15.14439	775	18237970	18240178	15.14439	775
chr2L	14934312	14936309	1000	29.06603	-1	-1	1384	4.712798	-0.68897	14934312	14936309	13.24318	694	14934312	14936309	13.24318	694
chr3L	7012361	7014294	1000	28.86334	-1	-1	1454	4.908960	-0.68897	7012361	7014294	15.54685	507	7012361	7014259	15.54	


TASK3: Identify a gene bound by the transcription factor CTCF

less significant_reproducible_peaks.bed.

chr2R	15816846	15822542	1000	65.86106	-1	-1	4667	5.000000	-0.69897	15816889	15822542	31.39334	2955	15816846	15822389	34.46772	1493
chr2R	11407189	11411117	1000	300062	-1	-1	3723	5.000000	-0.69897	11407189	11411117	31.14444	4770	11407189	11411106	30.13746	1113
chr2R	3765741	3769361	1000	59.14372	-1	-1	3584	5.000000	-0.69897	3765763	3769361	30.54167	1823	3765741	3769764	28.60205	883
chr2R	8250108	8253286	1000	57.23418	-1	-1	1664	5.000000	-0.69897	8250272	8253286	28.42407	1846	8250108	8253229	28.61011	1805
chr2R	1443810	1443600	1000	51.50832	-1	-1	2593	5.000000	-0.69897	14438080	1443600	25.74883	1470	14438100	14435993	25.76510	1875
chr2R	20905001	20908013	1000	50.66346	-1	-1	1751	5.000000	-0.69897	20905168	20908012	25.11064	849	20905001	20908013	25.55282	835
chr2L	3784187	3787617	1000	47.59915	-1	-1	2089	5.000000	-0.69897	3784187	3787587	24.06408	1252	3784394	3787617	23.53507	1105
chr2R	23000438	23003176	1000	46.46851	-1	-1	1685	5.000000	-0.69897	23000438	23003133	22.16511	827	23000493	23003176	24.29940	1270
chr2R	29311716	29314460	1000	44.72700	-1	-1	1185	5.000000	-0.69897	29311697	29314460	15.27883	1500	29311716	29314438	25.44817	853
chr2R	17140805	17143782	1000	40.29402	-1	-1	756	5.000000	-0.69897	17140844	17143792	21.52918	1307	17140805	17143755	18.74684	1587
chr3L	709868	713470	1000	39.97807	-1	-1	2688	5.000000	-0.69897	709898	713458	17.21245	1105	709868	713470	22.76562	1548
chr3L	10320245	10322223	1000	39.77525	-1	-1	766	5.000000	-0.69897	10320230	10322222	21.96455	867	10320245	10322219	18.71199	683
chr3R	5297200	5301501	1000	39.40033	-1	-1	1997	5.000000	-0.69897	5297204	5301424	16.87894	1549	5297200	5301501	22.52149	1499
chr2L	1490577	1493603	1000	39.33078	-1	-1	1471	5.000000	-0.69897	1490816	1493603	18.17768	778	1490577	1493520	21.15310	1401
chr2L	15652378	15654731	1000	38.77299	-1	-1	1152	5.000000	-0.69897	15654702	20.68340			15652378	15654731	18.08959	861
chr2R	8747757	8749585	1000	37.92001	-1	-1	1341	5.000000	-0.69897	8747844	8749585	15.76214	915	8747757	8749585	18.16787	937
chr4	403476	407635	1000	37.29410	-1	-1	2296	5.000000	-0.69897	403476	407635	20.93385	1101	403808	407619	16.36025	1458
chrX	4917629	4920230	1000	36.74131	-1	-1	952	5.000000	-0.69897	4917629	4920230	17.75416	808	4917725	4920133	18.98715	760
chrX	1558461	1558987	1000	31.26106	-1	-1	585	5.000000	-0.69897	1558887	15.73222	904	15584085	15589816	17.50870	865	
chr3R	29715081	29718338	1000	36.10140	-1	-1	1102	5.000000	-0.69897	29715366	29718338	18.21113	1312	29715081	29718266	17.89027	890
chr2L	10985838	10987572	1000	35.97155	-1	-1	1616	4.933538	-0.69897	10985838	10987572	14.94601	1419	10984783	10987551	21.02556	790
chr2R	12486866	12489784	1000	35.54567	-1	-1	883	5.000000	-0.69897	12486934	12.48577	835	12486966	12489715	15.08590	1418	
chr3R	23157677	23160005	1000	35.27787	-1	-1	1944	5.000000	-0.69897	23157677	23160005	18.37303	1022	23157677	23160005	16.90584	891
chr3R	12478945	12481724	1000	34.91052	-1	-1	942	5.000000	-0.69897	12478945	12481724	17.58954	998	12478953	12481722	17.32098	813
chr2R	16835449	16838261	1000	34.87539	-1	-1	1392	5.000000	-0.69897	16835449	16838261	20.08462	857	16835500	16838261	14.79647	633
chr2R	15377459	15377415	1000	34.53665	-1	-1	1392	5.000000	-0.69897	15377459	15377415	17.18255	1021	15377416	15377416	17.35440	1483
chrX	17750373	17753315	1000	34.48618	-1	-1	1473	5.000000	-0.69897	17750373	17753315	16.17680	657	17750611	17753290	18.30938	1154
chrX	19324811	19327657	1000	34.21655	-1	-1	1110	5.000000	-0.69897	19324811	19327657	17.89076	1523	19324850	19327657	16.32579	1452
chr2R	18620586	18623586	1000	33.95815	-1	-1	1392	5.000000	-0.69897	18620586	18623586	15.25917	1478	18620586	18623586	15.25917	1478
chrX	20523901	20526497	1000	33.79908	-1	-1	1308	4.629194	-0.69897	20523901	20526497	15.52917	1478	20523989	20526497	14.26991	524
chr2L	21602943	21606032	1000	33.14731	-1	-1	1536	4.681766	-0.69897	21602943	21606032	14.20872	1122	21602943	21606032	18.93859	1098
chr2L	488632	493325	1000	32.94414	-1	-1	3818	5.000000	-0.69897	489013	493300	11.13852	782	488632	493325	17.78562	2094
chr2L	18234263	18237041	1000	32.42468	-1	-1	1334	4.958431	-0.69897	18234263	18237041	17.16122	1220	18234263	18237041	17.16122	1220
chr2R	20937204	20939526	1000	32.17441	-1	-1	1342	5.000000	-0.69897	20937204	20939526	16.89755	1157	20939526	20939526	15.27486	767
chrX	9053717	9056305	1000	32.06366	-1	-1	1157	5.000000	-0.69897	9053944	9056305	14.64588	1770	9053717	9056261	17.41778	1063
chr2L	9471130	9474261	1000	31.91503	-1	-1	1287	3.362526	-0.69897	9471130	9474261	21.61000	1504	9471130	9474261	15.00421	824
chr2R	9941255	9944158	1000	31.87564	-1	-1	1722	5.000000	-0.69897	9941271	9944158	16.88435	1273	9941255	9944039	14.99125	613
chrX	17698548	17698546	1000	31.71828	-1	-1	2572	5.000000	-0.69897	17698548	17698546	16.09239	1730	17695254	17698502	15.42589	1746
chr2L	5368456	5367555	1000	31.68815	-1	-1	1280	5.000000	-0.69897	5368456	5367555	17.52272	1478	5368456	5367488	14.12543	1478
chr2R	21066643	21099152	1000	31.58955	-1	-1	1982	5.000000	-0.69897	21066643	21099152	17.16122	1220	21066706	21099060	14.42433	588
chrX	18515127	18518393	1000	31.22136	-1	-1	1357	5.000000	-0.69897	18515127	18518393	15.24316	1721	18515102	18518231	15.97820	1104
chrX	5289157	5290762	1000	31.00407	-1	-1	749	4.481441	-0.694574	5289157	5290762	17.92378	621	5289160	5290742	13.11669	774
chr3R	12460025	12470415	1000	30.91629	-1	-1	1045	5.000000	-0.69897	12460025	12470415	17.30095	1391	12460258	12470405	14.76447	1030
chr2L	12423671	12425806	1000	30.92734	-1	-1	969	5.000000	-0.69897	12423682	12425806	15.71591	1012	12423671	12425784	15.21143	1025
chr2L	9464072	9465785	1000	30.57547	-1	-1	567	4.716044	-0.69897	9464072	9465783	17.36820	375	9464247	9465785	13.20727	607
chr2L	504344	508420	1000	30.54281	-1	-1	3766	5.000000	-0.69897	504601	508883	16.51746	2013	504344	508420	14.02335	1755
chr2L	7255796	7259334	1000	30.54082	-1	-1	2500	5.000000	-0.69897	7255322	7259334	14.47154	1328	7255796	7259299	16.06928	1645
chr2L	1006002	1008305	1000	30.52374	-1	-1	650	4.722004	-0.69897	1006042	1007918	13.57045	483	1006002	1008305	16.95329	741
chr4	423068	426441	1000	30.49531	-1	-1	1721	3.010253	-0.547805	423068	426402	19.34848	158	423068	426441	11.13047	1021
chrX	18634288	18634860	1000	29.87691	-1	-1	1151	4.384789	-0.691826	18634288	18634860	17.30095	1391	18634511	18636860	12.57596	1302
chrX	19520357	19522559	1000	29.81669	-1	-1	1444	5.000000	-0.69897	19520371	19522559	15.37634	833	19520357	19522559	14.44035	894
chr2R	6149596	6153091	1000	29.64053	-1	-1	1288	5.000000	-0.69897	6149699	6153091	15.28493	1615	6149896	6153032	14.35560	1729
chr3R	14389486	14389316	1000	29.63008	-1	-1	2964	3.920002	-0.643572	14389486	14389316	17.89843	1964	14389743	14393093	11.73645	1423
chr3R	7161380	7163750	1000	29.54195	-1	-1	1332	4.612664	-0.69897	7161625	7163356	13.73262	913	7161380	7163750	16.26833	1087
chr3R	21518527	21521494	1000	29.53888	-1	-1	1676	4.783338	-0.69897	21518527	21521494	13.51230	1140	21518610	21521494	16.02658	1223
chr3R	11049683	11049914	1000	29.50841	-1	-1	1899	4.481441	-0.69897	11049683	11049914	17.52272	1478	11049698	11049914	17.51913	1412
chr2R	10857807	10900685	1000	29.49123	-1	-1	1484	5.000000	-0.69897	10857807	10900685	14.52089	793	10857808	10900685	14.52043	862
chr2L	21237736	21239531	1000	29.34975	-1	-1	1288	4.940788	-0.69897	21239339	21239531	15.75550	930	21237736	21239531	13.59425	1178
chrX	18237970	18240191	1000	29.13756	-1	-1	690	4.988967	-0.69897	18237970	18240191	15.14439	775	18237994	18240178	13.99317	756
chr2R	14934212	14936309	1000	29.06603	-1	-1	1384	4.712798	-0.69897	14934212	14936309	15.34315	1354	14934212	14936309	15.72265	391
chr3L	7012361	7014294	1000	28.86334	-1	-1	1454	4.808860	-0.69897	7012361	7014294	13.54685	827	7012375	7014295	15.31649	772
chr2L	20115753	20122180	1000	28.65843	-1	-1	985	4.707130	-0.69897	20115753	20122180	15.46847	593	20115759	20122171	13.00996	1058
chrX	12016585	12017135															

chr2L is the chromosome where the binding site is located. "chr2L" refers to the left arm of the second chromosome in *Drosophila melanogaster*. 6498467 is the start position of the CTCF binding site on the chromosome. BED file coordinates are 0-based, meaning that the first base of the chromosome is considered position 0. Thus, this binding site starts at the 6,498,467th base of chr2L. 6498838 is the end position of the CTCF binding site on the chromosome. In BED format, the end position is exclusive, meaning the actual binding site extends up to but does not include this position. Therefore, the binding site spans from base 6,498,467 to base 6,498,837, making it 371 bases long. NM_001298748.1_up_1_chr2L_6498646_f is a unique identifier for the binding site or the peak. It includes the gene name with which the site is associated, in this case, "NM_001298748.1", which could be a gene identifier in a specific database. The additional details (up_1_chr2L_6498646_f) provide context about the binding site's location, such as it being upstream of the gene, its chromosome, a specific base position, and the direction ("f" for forward strand). The "0" represents the score of the peak or binding site, which can indicate the strength or confidence in the site's identification. A score of "0" might suggest a default value in this context. The "+" means that the binding site is on the forward strand, which has implications for the directionality of any genes or regulatory elements associated with this site.

Discovering a CTCF binding site located on the left arm of chromosome 2L, at the precise coordinates of 6,498,467 to 6,498,837, unveils a fascinating glimpse into the intricate regulatory networks within *Drosophila melanogaster*. This sequence lies in proximity to the gene tagged as NM_001298748.1. Given CTCF's renowned role as an architectural protein, shaping the 3D organization of chromatin and dictating the rhythm of gene expression, this association is more than mere coincidence. It suggests a targeted regulatory influence, where CTCF could be modulating the expression of NM_001298748.1, thereby impacting fundamental biological processes from development and cell differentiation to the safeguarding of chromosomal architecture. This discovery not only highlights the complexity and precision of genetic regulation in *D. melanogaster* but also opens up avenues for exploring how such regulatory mechanisms contribute to the organism's biology and evolution.



```

#!/bin/bash

FULL_OUTPUT_DIR="full_output"

# Step 1: Quality Control
mkdir -p ${FULL_OUTPUT_DIR}/metrics

fastqc data/*.fastq.gz -o ${FULL_OUTPUT_DIR}/metrics/

# Step 2: Alignment with Bowtie2
mkdir -p ${FULL_OUTPUT_DIR}/alignment.

bowtie2 -x reference/bowtie2_index/genome \
    -U data/control.fastq.gz \ # Specifies the path to the FASTQ file for the control sample.
    > ${FULL_OUTPUT_DIR}/alignment/control.sam

bowtie2 -x reference/bowtie2_index/genome \ # Specifies the path to the Bowtie2 index.
    -U data/treatment_rep1.fastq.gz \
    > ${FULL_OUTPUT_DIR}/alignment/treatment_rep1.sam

bowtie2 -x reference/bowtie2_index/genome \
    -U data/treatment_rep2.fastq.gz \ # Specifies the path to the FASTQ file for treatment replicate 2.
    > ${FULL_OUTPUT_DIR}/alignment/treatment_rep2.sam

# Step 3: SAM to BAM Conversion and Mapping Quality Check
samtools view -bS ${FULL_OUTPUT_DIR}/alignment/control.sam \
    > ${FULL_OUTPUT_DIR}/alignment/control.bam

samtools view -bS ${FULL_OUTPUT_DIR}/alignment/treatment_rep1.sam \
    > ${FULL_OUTPUT_DIR}/alignment/treatment_rep1.bam

samtools view -bS ${FULL_OUTPUT_DIR}/alignment/treatment_rep2.sam \
    > ${FULL_OUTPUT_DIR}/alignment/treatment_rep2.bam

samtools flagstat ${FULL_OUTPUT_DIR}/alignment/control.bam \
    > ${FULL_OUTPUT_DIR}/metrics/control_mapping_quality.txt

samtools flagstat ${FULL_OUTPUT_DIR}/alignment/treatment_rep1.bam \
    > ${FULL_OUTPUT_DIR}/metrics/treatment_rep1_mapping_quality.txt

samtools flagstat ${FULL_OUTPUT_DIR}/alignment/treatment_rep2.bam \
    > ${FULL_OUTPUT_DIR}/metrics/treatment_rep2_mapping_quality.txt

# Step 4: Peak Calling with MACS2
mkdir -p ${FULL_OUTPUT_DIR}/peaks

macs2 callpeak -t ${FULL_OUTPUT_DIR}/alignment/treatment_rep1.bam \ # Specify the treatment replicate 1 BAM file as the
target.
    -c ${FULL_OUTPUT_DIR}/alignment/control.bam \
    -f BAM -g dm -n treatment_rep1 \
    --outdir ${FULL_OUTPUT_DIR}/peaks -q 0.05
    --call-summits --nomodel --extsize 147

macs2 callpeak -t ${FULL_OUTPUT_DIR}/alignment/treatment_rep2.bam \

```

```
-c ${FULL_OUTPUT_DIR}/alignment/control.bam \  
-f BAM -g dm -n treatment_rep2 \  
--outdir ${FULL_OUTPUT_DIR}/peaks -q 0.05 \  
--call-summits --nomodel --extsize 147
```

Step 5: Reproducibility Assessment with IDR

mkdir -p \${FULL_OUTPUT_DIR}/idr # Create a directory for storing idr results.

idr --samples \${FULL_OUTPUT_DIR}/peaks/treatment_rep1_peaks.narrowPeak \
\${FULL_OUTPUT_DIR}/peaks/treatment_rep2_peaks.narrowPeak \
--output-file \${FULL_OUTPUT_DIR}/idr/treatment_idr_output.txt \
--log-output-file \${FULL_OUTPUT_DIR}/idr/treatment_idr.log

awk 'BEGIN {OFS="\t"} {\$12 = -log(\$12)/log(10); print}' \${FULL_OUTPUT_DIR}/idr/treatment_idr_output.txt >
\${FULL_OUTPUT_DIR}/idr/treatment_idr_output_log10p>

Step 6: Filtering Peaks Based on IDR Output

mkdir -p \${FULL_OUTPUT_DIR}/final_peaks

awk '\$12 < 0.05' \${FULL_OUTPUT_DIR}/idr/treatment_idr_output.txt \
> \${FULL_OUTPUT_DIR}/final_peaks/significant_reproducible_peaks.bed

SUBSET

```
#!/bin/bash
```

```
# Step 0: Create subsets of the original fastq files for testing purposes to speed up the process.
```

```
echo "Subsetting data for testing..."
```

```
mkdir -p sub_data # Create a directory for the subsetting data.
```

```
# Use seqtk to sample 1000 reads from the original fastq.gz files, then gzip the output for FastQC compatibility.
```

```
seqtk sample -s100 data/control.fastq.gz 10000 | gzip > sub_data/sub_control.fastq.gz
```

```
seqtk sample -s100 data/treatment_rep1.fastq.gz 10000 | gzip > sub_data/sub_treatment_rep1.fastq.gz
```

```
seqtk sample -s100 data/treatment_rep2.fastq.gz 10000 | gzip > sub_data/sub_treatment_rep2.fastq.gz
```

```
# Step 1: Run FastQC for quality control on the subsetting fastq.gz files.
```

```
echo "Running FastQC for quality control..."
```

```
mkdir -p output/metrics # Create a directory for FastQC reports.
```

```
fastqc sub_data/*.fastq.gz -o output/metrics/ # Run FastQC on all subsetting fastq.gz files and output the reports to the metrics directory.
```

```
# Step 2: Align reads to the reference genome with Bowtie2.
```

```
mkdir -p output/alignment # Create a directory for the alignment output.
```

```
# Align each subsetting fastq.gz file to the reference genome using Bowtie2, outputting SAM files.
```

```
bowtie2 -x reference/bowtie2_index/genome -U sub_data/sub_control.fastq.gz > output/alignment/sub_control.sam
```

```
bowtie2 -x reference/bowtie2_index/genome -U sub_data/sub_treatment_rep1.fastq.gz > output/alignment/sub_treatment_rep1.sam
```

```
bowtie2 -x reference/bowtie2_index/genome -U sub_data/sub_treatment_rep2.fastq.gz > output/alignment/sub_treatment_rep2.sam
```

```
# Step 3: Convert SAM files to BAM format and check mapping quality.
```

```
echo "Converting SAM to BAM and checking mapping quality..."
```

```
# Convert SAM to BAM using samtools for each alignment file.
```

```
samtools view -bS output/alignment/sub_control.sam > output/alignment/sub_control.bam
```

```
samtools view -bS output/alignment/sub_treatment_rep1.sam > output/alignment/sub_treatment_rep1.bam
```

```
samtools view -bS output/alignment/sub_treatment_rep2.sam > output/alignment/sub_treatment_rep2.bam
```

```
# Generate mapping quality reports for each BAM file using samtools flagstat.
```

```
samtools flagstat output/alignment/sub_control.bam > output/metrics/sub_control_mapping_quality.txt
```

```
samtools flagstat output/alignment/sub_treatment_rep1.bam > output/metrics/sub_treatment_rep1_mapping_quality.txt
```

```
samtools flagstat output/alignment/sub_treatment_rep2.bam > output/metrics/sub_treatment_rep2_mapping_quality.txt
```

Step 4: Call peaks using MACS2 with a fixed extension size.

mkdir -p output/peaks # Create a directory for peak calling output.

Use MACS2 to call peaks on each treatment BAM file against the control, specifying parameters like genome size, q-value cutoff, etc.

```
macs2 callpeak -t output/alignment/sub_treatment_rep1.bam -c output/alignment/sub_control.bam -f BAM -g dm -n  
sub_treatment_rep1 --outdir output/peaks -q 0.05 --call-summits --nomodel --extsize 147
```

```
macs2 callpeak -t output/alignment/sub_treatment_rep2.bam -c output/alignment/sub_control.bam -f BAM -g dm -n  
sub_treatment_rep2 --outdir output/peaks -q 0.05 --call-summits --nomodel --extsize 147
```

Step 5: Use IDR (Irreproducible Discovery Rate) to assess the reproducibility between biological replicates' peak sets.

echo "Assessing reproducibility with IDR..."

```
idr --samples output/peaks/sub_treatment_rep1_peaks.narrowPeak \  
    output/peaks/sub_treatment_rep2_peaks.narrowPeak \  
    --output-file output/idr/sub_treatment_idr_output.txt \  
    --plot \  
    --log-output-file output/idr/sub_treatment_idr.log
```

Step 6: Filter for significant, reproducible peaks based on IDR output.

echo "Filtering significant, reproducible peaks based on IDR output..."

Use awk to filter the IDR output for entries with a column 12 value (adjusted p-value) less than 0.05, indicating significant reproducibility.

```
awk '$12 < 0.05' output/idr/sub_treatment_idr_output.txt > output/final_peaks/significant_reproducible_peaks.bed
```

echo "Pipeline execution for subsetted data completed."